



Cordell International, Inc.
Installation Instructions
200 Series Steel Outswing Door

For your safety read all instructions
This document is provided as a GUIDELINE

for the proper installation of the Cordell International 200 Series Steel Outswing Door

200 Series Steel outswing for components for installation
Installation is common between all sizes

Quantity	Part #	Description
1	200	200 Series Steel Outswing Door assembly

Provided by Installer

Sealant, Silicone base

Screws recommended

min # 8 x 1 1/4" 1/4" hex head screw door installation in the exterior frame
min # 8 x 2" Pan head screw at the latch and deadbolt

Non-hardening putty tape and putty knife, screw driver or reversible drill, and shims

Note: These instructions are recommend guidelines for proper installation of the included components.

Dimensions for notes that use specific screws must be held to the size to ensure proper fit

The Drawings included are Guidelines. Actual door may vary according to size and style

Parts of the door may have been omitted for clarity

These instructions are written under the pretense that the opening has been properly prepped and squared prior to beginning the installation process